

INSTALLATION AND USE

Surface Preparation

Ensure that all supports are healthy and clean, free of irregularities. For wet rooms (shower, basin...), waterproof the surface before tiling.

Zellige Preparation

Before laying, immerse each tile in the water for few minutes and then let them dry for about 15 minutes.

Pre-assembled panels : spray water on the back of the panel to slow down the setting glue.

«Edge to edge» Installation

No spacer ! All our zelliges must be placed «edge to edge» with a minimum possible grout to achieve a uniform, authentic surface after grouting.

Double bonding

Due to the uncalibrated thickness, we recommend double-gluing both support and back of the tile to ensure 10mn adhesive between panel and support.

Grouting

Use a very liquid grout all over the surface to fill all thin joints with it. After grouting, carefully clean the tiles to remove cement veil.

Cleaning and Maintenance

Take care to take off all adhesive spot after installation

hiseled zone will be sealed with solvent-based stain protector, Fila W68 or equivalent.

No specific cleaning instruction



Professionnals:

bonjour@zelij.com

Private & general enquiries:

contact@zelij.com

+33 (0)562 481 809

[@ateliers.zelij](https://www.ateliers.zelij.com)

www.zelij.com

All right reserved © 2026

Ateliers Zelij | Créateurs de surfaces